

BOMBELLI GIANCARLO S.p.A.

Capitale Soc. Euro 600.000 int. versato
Sede Amministrativa:
20015 S. Lorenzo di Parabiago (Milano - Italy)
SS. del Sempione 49/51
S. 0331.55.10.25 (7 linee)
P.O. Box 88
TELEFAX 0331.55.16.72
E-Mali: bombelli@bombelli-spa.com
E-Mali: Sales@bombelli-spa.com
http://www.bombelli-spa.com
Paritia IVAI TO0785890120
REA. Milano 1028058
REA. Varese 157300
Codice Fiscale e Numero Isozizione
Registro Imprese di Varese 00785890120
Meccanografico Varese 028137
Sede Legale:

Sede Legale: 21052 Busto Arsizio (Varese) Via Zappellini, 6



Pulling over-lasting machine

SincronZero MW

made in Italy 100%

SincronZero MW the pulling-over lasting machine that allows to program infinitely, working on a 12" colour LCD, in a simple and ergonomic way:

 all the times and the powers that intervene in the lasting phase such as the closing pressure of the pincers and of the teflon band and the pressing;

the wipers closing, the pincers encirclement, the position and power of the pincers pulling, the lower support pulling position and inclination, the side bands position and exclusion;

the lasting system of the connection between ball and waist realized by the motorized side blocks which are programmable in position and pressure and independent on the right and left side;

cement path margins with sizes grading adjustment of the injectors.

SincronZero MW, great flexibility and precision of working thanks to:

the quick system of change of all the pincers that allows to shape quickly different types of shoes, moving swiftly from a sharp toe to a classic round toe;

the opportunity to range, simply pressing a button, from an exclusive and patented system of cement distribution through programmable nozzles, complete from the toe to the waist to a mixed system in which the crown is used for the toe and the nozzles for the ball and waist according to the characteristics of the shoe being worked;

the possibility to use only one injector for the toe with very sharp lasts;

the automatic reading of the last size;

the use of the USB technology that allows to carry out, in a few instants and in a completely autonomous way, the operations of restoring, filing, copying, transferring and updating of the data;

the self-diagnostic.

it can be customized

 last blocking: for very shaped lasts; it blocks the rear part of the last during the wipers closing:

 motorized adjustment of the BC pincers: change of the position of the BC pincers from the operator panel;

 stuttering of the ABC pincers: it is suggested for very delicate uppers, it opens and closes with a certain frequency the ABC pincers to avoid tears during the pulling;

 programmable motorized adjustment of the teflon band: it is useful if teflon bands with different thickness according to the last type are used;

 rear support with rh/lh automatic positioning and pressure compensation:

adjustment of the inclination of the rear support;

 Teflon band unit with USA side connections: it allows the use of the teflon band USA type;

 external tank to lubricate the wipers: it avoids the machine stop following the opening of the cover;

reset through knee lever at bar and exclusion of the reset pedal;

projector of red light for dark leather;

wheels for machine handling;

software for serial connection between SincronZero and MarkZero; to allow to only one operator to work on both machines in a more

hardware key to protect programs.

